How to set/reset the combination on your Safe Skies™ TSA Lock

1

Align all the dials on the front of the lock to zero (or your actual combination if you want to change it again). All Safe Skies™ Luggage Locks are preset at the factory to open at zero so that they align with the red lines.



2

Pull the shackle up and turn it 90° in either direction and press the shackle **firmly** down.

3

While **firmly** holding shackle down, set your new combination, so that it aligns with the red lines. (1-2-3-4 in this example).
Do not release shackle until you have completed setting your new combination.

4

Once new combination is set, release shackle and pull shackle up completely. Return shackle back to locked position. Lock should not lock since it is set to new combination. Turn one or more dials and the shackle should now lock.

Please make sure to remember your combination!